#### Ordering information

# LHA75F

A 75









High voltage pulse noise type : EAP series Low leakage current type : EAM series

\*A higher current rating EMI/EMC filter may be recommended in view of the other devices that could be connected in parallel with the power supply.

- Series name
   Single output
   Output wattage
- 4)Universal input
- ⑤Output voltage
- Optional \*1
   C : with Coating
   G: Low leakage current
  - J4: EP(Tyco)connector type
  - Y: with Potentiometer

For option details, refer to instruction manual 6.

This power supply is manufactured by SMD technology. The stress to PCB like twisting or bending causes the defect of the unit, so handle the unit with care. \*Make sure necessary tests will be carried out on your end equipment with the power supply installed in accordance with any required EMC/EMI regulations.


MODEL	LHA75F-3R3-Y	LHA75F-5	LHA75F-12	LHA75F-15	LHA75F-24	LHA75F-36	LHA75F-48
MAX OUTPUT WATTAGE[W] *2	39.6	60	75.6	75	76.8	75.6	76.8
DC OUTPUT *2	3.3V12A	5V12A	12V6.3A	15V5A	24V3.2A	36V2.1A	48V1.6A

### **SPECIFICATIONS**

	MODEL		LHA75F-3R3-Y	LHA75F-5	LHA75F-12	LHA75F-15	LHA75F-24	LHA75F-36	LHA75F-48							
	VOLTAGE[VAC] *2		85 - 264 1 φ (Refer to "Derating" and Instruction Manual 3)													
	CHDDENTIAL	ACIN 100V	0.6typ 0.8typ 0.9typ													
	CURRENT[A] ACIN 230V															
	FREQUENCY[Hz]		50 / 60 (45 - 66)													
	EEEICIENCVI9/1	ACIN 100V	74.0typ	79.0typ	84.5typ	85.5typ	86.0typ	87.5typ	87.5typ							
NPUT	EFFICIENCY[%]	ACIN 230V	75.0typ	81.0typ	86.5typ	87.5typ	88.0typ	89.5typ	89.5typ							
	POWER FACTOR (Io=100%)	ACIN 100V	0.96typ	0.97typ												
		ACIN 230V	0.70typ 0.80typ													
	INRUSH CURRENT[A]	ACIN 100V	- 71 ( )													
	INNUSH CONNENT[A]	ACIN 230V	35typ (lo=100%) Ta=25 <sup>°</sup> C at cold start													
	LEAKAGE CURRENT[mA]		0.40 / 0.75max (ACIN 100V / 240V 60Hz, lo=100%, According to IEC62368-1)													
	VOLTAGE[V]		3.3	5	12	15	24	36	48							
	CURRENT[A]	*2	12.0	12.0	6.3	5.0	3.2	2.1	1.6							
	LINE REGULATION[	mV] *3	20max	20max	48max	60max	96max	144max	192max							
	LOAD REGULATION	[mV] *3	40max	40max	100max	120max	150max	240max	240max							
	RIPPLE[mVp-p]	0 to +50°C *7	80max	80max	120max	120max	120max	150max	150max							
		-10 to 0℃	140max	140max	160max	160max	160max	200max	200max							
OUTPUT		lo=0 to 15%	300max	300max	360max	500max	500max	500max	500max							
	DIDDLE NOIGEL V	0 to +50°C *7	120max	120max	150max	150max	150max	250max	250max							
	RIPPLE NOISE[mVp-p]	-10 to 0℃	160max	160max	180max	180max	180max	300max	300max							
	**	lo=0 to 15%	360max	360max	400max	600max	600max	600max	600max							
		0 to +50°C *7	50max	50max	120max	150max	240max	360max	480max							
		-10 to +50°C <b>*</b> 7	60max	60max	150max	180max	290max	450max	600max							
	DRIFT[mV] *5		20max	20max	48max	60max	96max	144max	192max							
	START-UP TIME[ms]		100typ (ACIN 100V, Io=100%)													
	HOLD-UP TIME[ms]		20typ (ACIN 100V, Io=100%)													
	OUTPUT VOLTAGE ADJUSTMENT RANGE[V]		2.85 to 3.63	Fixed ("Y"option	is available for a	djusting output vo	oltage between ±	10%)								
	OUTPUT VOLTAGE SETTING[V]		3.30 to 3.40	4.90 to 5.30	11.50 to 12.50	14.40 to 15.60	23.00 to 25.00	34.50 to 37.50	46.00 to 50.0							
DOTECTION	OVERCURRENT PROT	ECTION	Works over 105	% of rating and	recovers automa	ntically										
PROTECTION CIRCUIT AND	OVERVOLTAGE PROTECTION		4.00 to 5.25	5.75 to 7.00	13.80 to 16.80	17.25 to 21.00	27.60 to 33.60	41.40 to 50.40	55.20 to 67.20							
OTHERS	OPERATING INDICATION		Not provided													
JIIIENS	REMOTE SENSING		Not provided													
	INPUT-OUTPUT		AC3,000V 1minute, Cutoff current = 10mA, DC500V 100M $\Omega$ min (At Room Temperature)													
SOLATION	INPUT-FG		AC2,000V 1minute, Cutoff current = 10mA, DC500V 100M $\Omega$ min (At Room Temperature)													
	OUTPUT-FG		AC500V 1minute, Cutoff current = 25mA, DC500V 100M $\Omega$ min (At Room Temperature)													
	OPERATING TEMP., HUMID. AND A	ALTITUDE *2	1 7 7													
NVIRONMENT	STORAGE TEMP., HUMID. AND	ALTITUDE	-20 to +75°C, 20 - 90%RH (Non condensing), 9,000m (30,000feet) max													
INVINOINIEIVI	VIBRATION		10 - 55Hz, 19.6m/s² (2G), 3minutes period, 60minutes each along X, Y and Z axis													
	IMPACT		196.1m/s² (20G), 11ms, once each X, Y and Z axis													
SAFETY AND	AGENCY APPROVAL	LS	UL62368-1, c-UL (equivalent to CAN/CSA-C22.2No.62368-1), EN62368-1													
NOISE	CONDUCTED NOISE		Complies with FCC-B, VCCI-B, CISPR11-B, CISPR32-B, EN55011-B, EN55032-B													
REGULATIONS	HARMONIC ATTENU	JATOR *6	Complies with IEC61000-3-2 (Class A)													
	CASE SIZE/MEIGHT					X1.07X5.91 inches] (WXHXD) / 190g max										
OTHERS	CASE SIZE/WEIGHT		30 XZ1 X 130111	111 [ 1.57 / 1.07 / 3	).91 IIICHES] (VV /	(11/0 <i>b)</i> / 130g 11	iux		Convection/Forced air (Requires external fan) (Refer to "Derating" and Instruction Manual 3)							


- The listed options may affect the published standard specifications. Please contact us for detailed product specifications.
- Derating is required.
- At low load conditions, the burst mode operation will start. To check load regulation, you
- will need to measure the characteristics at average mode with instruments. This is the value that measured on measuring board with capacitor of 22  $\mu$  F and 0.1  $\mu$  F at 150mm from output terminal. Measured by 20MHz oscilloscope or Ripple-Noise meter (Equivalent to KEISOKU-GIKEN:RM104).
- Ripple and ripple noise spec is change at lo=0 to 15% by burst operation.
- Drift is the change in DC output for an eight hour period after a half-hour warm-up at 25°C, with the input voltage held constant at the rated input/output.
- Please contact us about another class.
- 3.3V and 5V output product, the maximum temperature of 40°C. To meet the specification, do not operate overload condition.
- Parallel operation is not possible.
- Sound noise may be generated by power supply in case of pulse load.

## **Block diagram**



### **External view**

\* External size of option is different from standard type.



- ¾ 4 Mounting holes are existing.
- The back side of PCB of the power supply is assembled some SMDs.
  - Be careful not to bump against the attached area by vibration.
- W Use the spacer of 8mm [0.31] length or more for isolation. And do not use press-fitting bush.
- Point ①, Point ② are thermometry points. Please refer to Instruction Manual 3.

I/O Connector		Mating connector		Terminal			
CN1 B3	DODE VIII	VHR-5N	Chain	SVH-21T-P1.1			
	B3P5-VH	VHK-5IN	Loose	BVH-21T-P1.1			
CN2 B	DOD VIII	VHR-6N	Chain	SVH-21T-P1.1			
	ROD-AH	VHK-6N	Loose	BVH-21T-P1.1			

(Mfr: J.S.T.)

- % I/O Connector is Mfr.J.S.T.
- ※ Option:-J4:EP (Tyco Electronics) connector type.


CN1		CN2				
Pin No.	Input		Pin No.	Output		
1	AC(L)		1 to 3	-V		
2			1 10 3	-v		
3	AC(N)		4 to 6	+V		
4			4 10 0	+v		
-	EG	l				

- % Keep drawing current per pin below 5A for CN2.
- % Tolerance : ±1 [±0.04]
- % Weight : 190g max
- ※ PCB Material / thickness : FR-4 / 1.6mm [0.06]
- Dimensions in mm, [ ]=inches
- ※ Please connect safety ground to FG terminal on the unit.

## **Assembling and Installation Method**


#### Installation method

- ■This power supply is manufactured by SMD technology. The stress to P.C.B like twisting or bending causes the defect of the unit, so handle the unit with care.
- ■In case of metal chassis, keep the distance between d1 & d2 for to insulate between lead of component and metal chassis, use the spacer of 8mm or more between d1. If it is less than d1 & d2, insert the insulation sheet between power supply and metal chassis.



Power supply


- ■There is a possibility that it is not possible to cool enough when the power supply is used by the sealing up space as showing in right figure. Please use it after confirming the temperature of point ① and point ② of Instruction Manual right figure.
- ■(F) mounting is not possible when unit is with case cover, but if you need to operate unit by (F) positioning with case cover, temperature / load derating is necessary. For more details, please contact our sales or engineering departments.




## **Mounting screw**

 $\blacksquare$ The mounting screw should be  $\phi$ 3mm. The hatched area shows the allowance of metal parts for mounting.

# LHA30F



# LHA50F, LHA75F, LHA100F, LHA150F, LHA300F




- ■If metallic fittings are used on the component side of the board, ensure there is no contact with surface mounted components.
- ■This product uses SMD technology. Please avoid the PCB installation method which includes the twisting stress or the bending stress.




## Derating


Derating curve for input voltage




LHA30F Ambient temperature derating curve (Reference value)




LHA50F-3R3-Y, -5, -24, -36, -48 Ambient temperature derating curve (Reference value)




LHA75F-3R3-Y, -5 Ambient temperature derating curve (Reference value)



LHA50F-12, -15 Ambient temperature derating curve (Reference value)




LHA75F-12, -15, -24, -36, -48 Ambient temperature derating curve (Reference value)




# **COSEL** | LHA-series

## Derating


LHA100F-5
 Ambient temperature derating curve (Reference value)




 LHA150F-12 Ambient temperature derating curve (Reference value)




LHA150F-12-SN
 Ambient temperature derating curve (Reference value)



LHA300F-12-Y
Ambient temperature derating curve (Reference value)




 LHA100F-12, -15, -24, -36, -48
 Ambient temperature derating curve (Reference value)




■ LHA150F-24, -36, -48


Ambient temperature derating curve (Reference value)



 LHA150F-24-SN, -36-SN, -48-SN Ambient temperature derating curve (Reference value)




 LHA300F-24-Y, -48-Y
 Ambient temperature derating curve (Reference value)






## Derating

# LHA300F-12-SNY Ambient temperature derating curve (Reference value)



# LHA300F-24-SNY, -48-SNY Ambient temperature derating curve (Reference value)



- ■The operative ambient temperature is different by with / without chassis cover or mounting position. Note: In the hatched area, the specification of Ripple, Ripple Noise is different from other area.
- ■Make sure the case temperature at point ① and point ② is less than the temperatures shown in Shown in Instruction Manual 3.
- ■The ambient temperature should be measured 5 to 10 cm away from the power supply so that it won't be influenced by the heat from the power supply. Please contact us for more details.

### **Instruction Manuals**

Please see catalog and instructionmanual before you use.

Instruction Manuals https://en.cosel.co.jp/product/powersupply/LHA/ Before using our product https://en.cosel.co.jp/technical/caution/index.html





### **Basic Characteristics Data**

Model Circuit met	Oireanit mareth and	Switching frequency [kHz] *1 *2	Input current *3 [A]	Inrush current protection	PCB/Patt	Series/Parallel operation availability			
	Circuit method				Material	Single sided	Double sided	Series operation	Parallel operation
LHA30F	Flyback converter	30 to 120	0.62	Thermistor	FR-4	-	Yes	Yes	No
LHA50F	Flyback converter	30 to 120	1.05	Thermistor	FR-4	-	Yes	Yes	No
LHA75F	Active filter	25 to 155	0.9	Thermistor	FR-4	-	Yes	Yes	No
	Flyback converter	60 to 115							INO
LHA100F	Active filter	20 to 150	1.2	Thermistor	FR-4	_	Yes	Yes	No
	Flyback converter	45 to 110		11161111115101	1 11-4	_	168	168	INO
1 441505	Active filter 20 to 150	4.0	Thermistor	FR-4		Yes	Yes	No	
LHA150F	LLC resonant converter	90 to 280	1.8	THETHISTOR	г <del>п-4</del>	-	res	res	No
LHA300F	Active filter	20 to 150	0.5	Thermistor	FR-4	-	Yes	Yes	No
	LLC resonant converter	65 to 200	3.5						No

- \*1 The value changes depending on input and load.
- \*2 Burst operation at light loading, frequency is change by use condition. Please contact us about detail.
- \*3 The value of input current is at ACIN 100V and rated load.